


CONFIGURATION KIT - 14469720

USB key and SMART ASSISTANT software for wireless programming

iN



DESCRIPTION

Use the USB transmitter to wirelessly set and configure devices in the SMART system. For this purpose, the USB transmitter must be connected to a computer with the SMART Assistant software installed.

The USB transmitter provides for communication (re-mote management) between SMART devices and the configuration SMART Assistant software using two-way communication.

According to individual types of devices, it is possible to store, edit and remove codes of transmitters and functions assigned to individual codes in the memory of the devices. Parameters of devices (time of closing, delays, output levels, rise and fall times, etc.) can be set. To increase the range of a spread network of de-vices, it is possible to set multiple retranslation and the manner of searching for devices for the purpose of re-mote management so that remote management cannot be misused for undesired changes to settings of devic-es.

FIRST USE

Before connecting the USB transmitter to the PC the SMART Assistant software must be installed. Down-load it from Performance in Lighting web site

After installation has completed, the SMART Assistant software along with the USB transmitter is ready for use.

Technical data	P8 TR USB
Communications protocol:	USB 2.0 full speed
Supported OS:	Windows 7 or later Windows XP and 64-bit Windows Vista and 64-bit
Operating temperature:	0 ÷ + 35 °C
Frequency:	868 MHz
Range:	150 m in open space
Weight:	10 g
Dimensions:	75 × 20 × 8 mm

It is forbidden to do any technical modifications on the device!